



CONTROLLING EMISSIONS  
PROTECTING THE ENVIRONMENT  
CONTINUOUS IMPROVEMENT



# Best Available Technique for Emptying Bags Containing Brominated Flame Retardants (BFRs)

An appendix to the Code of Good Practice



## Introduction

This document is an addendum to the Code of Good Practice and is valid for all use-processes where BFRs are delivered in 20-25 kg bags or 500-1000 kg big bags. The objective of this document is to offer advice to minimize emissions when emptying and disposing of BFR packaging.

### What is the best technique to empty BFR containing packaging?

**The type of packaging is influencing the amount of emissions during emptying and what will be left per mton used BFR.**

- Always wear proper PPE: respirator, gloves, protective clothing.
- Switch on the ventilation system before starting unloading the bags.
- Put the BFR bags in front of the loading point.

**An air aspiration system equipped with well-operated fabric filters is recommended as the minimum standard to reduce dust emissions to air.**

Dust emissions can also be reduced when the air stream is sucked into the mixer when dosing. Further, it is important to recognize that diffuse emissions (e.g. via open windows, doors and workers clothing) can be an important emission source as well! It is recommended to implement procedures requiring immediate cleaning of the work place after finalisation of a batch. An air extraction/ventilation system equipped with adequate fabric filters is essential to collect dust during this operation.

#### Best available technology for the ventilation system.


A tiered system with different filters in a row can be used to achieve emissions lower than 0.03 mg/Nm<sup>3</sup>. The first filter is a standard bag filter (to catch the bulk dust). This will result in a remaining dust emission of <5 mg/Nm<sup>3</sup>. Secondly, the air is sent to a sintered lamella filter which brings the dust emission back to <1 mg/Nm<sup>3</sup>. Finally an absolute filter is used which brings the emissions to below <0.03 mg/Nm<sup>3</sup>. The last two operations are needed when the aim is “zero emission”.

The air aspiration system should only run during emptying/unloading of the bags and be switched off afterwards to prevent a continuous emitting of dust via the bag filters (the so-called tailing effect).

A control system should be in place to ensure that the filters are cleaned, shaken or replaced at right intervals.

Because of the small particle size, some dust formation will take place even in the presence of a good air extraction system. Dust on the floor and equipment should preferably be collected by means of a proper vacuum cleaner (i.e. a cleaner equipped with filters that collect small particles or a cleaner connected to the air aspiration system) or a broom. Cleaning with water should be avoided!

#### To understand how much residue is left in empty packaging:



Deca residue left after emptying 25 kg bag: 150 - 200 g.

Deca residue left after emptying 1000 kg big bags: 500 - 600 g.

We expect use of best practices will significantly lower these residues.

For 500 and 1000 kg big bags, the highest efficiency is probably achieved by using a vibrating platform (bag hopper). An example of this technique can be found at: <http://www.directindustry.com/soc/flomat-bagfilla-21954.html>

There are different types of packaging, mainly split in 20-25 kg bags (PE or paper) and big bags of 500 or 1000 kg.

### Best technique for 20-25 kg bags



**1.** Start the ventilation system. Put the bag under the ventilation system on top of the funnel or other filling opening.



**2.** Place the bag in such a way that the fill spout is facing the operator. Cut the bag on the opposite side of the fill spout.



**3.** Turn the bag with cut side down to empty bag.



**4.** Shake bag vigorously.



**5.** Notice the spout. If the bag was cut on the opposite side, the fill spout would be full of product. Notice the exhaust port on the ventilation system. The exhaust hood should be adequate to capture the fine dust.



**6.** Roll up bag to get all of the air out.



**7.** Place rolled up bag in a plastic bag for disposal.



**8.** Close the plastic bags and put this one full of empty paper bags in a shipping container for proper disposal.

## Best technique for big bags of 500 or 1000 kg



**1.**

Check if ventilation system is running.

Mount big bag above Hopper.



**2.**

Open bottom closures.



**3.**

Secure sack to Hopper to prevent spillage.



**4.**

Product should discharge by gravity.



**5.**

Shake all Corners of sack vigorously.



**6.**

Shake all four corners of sack vigorously.

Take care that the empty packaging is folded carefully and packed into a PE plastic bag for disposal. Close the plastic bag and put this one full of empty bags in a shipping container for proper disposal.



### For further information:

contact the VECAP Product Steward,  
Paul Adriaenssens at [qualipa@skynet.be](mailto:qualipa@skynet.be)  
or visit [www.vecap.info](http://www.vecap.info)

VECAP is a voluntary initiative of the European Brominated Flame Retardant Industry Panel – EBFRIP together with the industry's global organisation, the Bromine Science and Environmental Forum – BSEF

**EBFRIP**  
A SECTOR GROUP OF CEFIC

**BSEF**  
Bromine Science and Environmental Forum